

Century

Model W540

Wall Post Indicator

Adjustable and easy to use.




Century Wall Post Indicator



- Wall Post Indicator to be used with Non Rising Stem (NRS) Gate Valves
- Features a rotating indicator that is visible from a distance to show the valve's position, OPEN or SHUT, easily adjusted on site.
- Fusion-bonded coating in compliance with AWWA C550
- UL Listed to UL 326 and FM 1110

Material List - CENTURY Wall Post Indicator.

PART NAME	MATERIAL	SPECIFICATION
Lifting Eye Bolt	Steel	ASTM A105
Hex Nut	Steel	ASTM A105
Washer	Stainless Steel	AISI 304
Hand Wheel	Ductile Iron	ASTM A536 65-45-12
Op Nut	Stainless Steel	ASTM A351 CF8
Hex Screw	Steel	ASTM A105
Hex Nut	Steel	ASTM A105
Washer	Steel	ASTM A105
External Circlip	Al	AISI 606
Indicator Stand	Stainless Steel	ASTM A351 CF8
Indicator Panel	Al	ASTM A108
Hex Nut	Stainless Steel	SS304
Washer	Stainless Steel	SS304
Window	Plastic	LEXAN-UN
Window Cover	Carbon Steel	ASTM A307B
Seal Ring	Rubber	EPDM
Stud	Steel	ASTM A105
Washer	Steel	ASTM A105
Hex Nut	Steel	ASTM A105
Barrel	Cast Iron	ASTM A126B
Stand Pipe	Steel	ASTM A53
Stem	Steel	SS1045
Cotter Pin	Stainless Steel	SS304
Crane Coupling	Ductile Iron	ASTM A536 65-45-12
Plug	Stainless Steel	SS304
Cover	Cast Iron	ASTM A126B
Cross Recessed Countersunk	Stainless Steel	SS304
Washer	Steel	ASTM A105



Field Adjustment Instructions:

- 1- Remove the top section from the indicator post assembly.
- 2- Set the "OPEN" and "SHUT" targets according to the appropriate valve size.
- 3- Reattach the top section to the indicator post assembly.

Note: Design and materials are subject to change without notice.

sales@centuryvalves.com

CENTURY Valves & Hydrants, Bristol Rhode Island - United States - www.centuryvalves.com